

ASSEMBLING INSTRUCTIONS

1640

CAUTION :

THIS ITEM IS MADE OF LAMINATED PARTICLE BOARD AND MEDIUM DENSITY FIBRE BOARD
TO BE ASSEMBLED ON A DRY, SOFT, SMOOTH AND CLEAN SURFACE . DO NOT USE DETERGENT OR CHEMICAL. AVOID DAMP AND SUNLIGHT.

STEP 1	CHECK YOUR HARDWARE	6649
	SCREW #9 X 1 1/2"	30 PCS
	SCREW CAP	14 PCS
	WOOD DOWEL M8 X 25	21 PCS
	CORNER BLOCK	4 PCS
	SCREW M3 X 20	4 PCS
	SHELF SUPPORT	5 PCS
	HANDLE	4 PCS
	SCREW PAN HEAD #6 X 22	8 PCS
	METAL RUNNER	2 SETS
	SCREW M4 X 12	24 PCS
	SCREW M4 X 30	8 PCS
	HINGES	4 PCS
	SCREW M3.5 X 14	16 PCS
	HOUSING D:12/9.5MM	8 PCS
	EURO BOLT	8 PCS

TOOLS REQUIRED :			
	SCREW DRIVER		HAMMER

