

ASSEMBLING INSTRUCTIONS

1985

CAUTION :

THIS ITEM IS MADE OF LAMINATED PARTICLE BOARD AND MEDIUM DENSITY FIBRE BOARD

TO BE ASSEMBLED ON A DRY, SOFT, SMOOTH AND CLEAN SURFACE . DO NOT USE DETERGENT OR CHEMICAL. AVOID DAMP AND SUNLIGHT.

STEP 1	CHECK YOUR HARDWARE	8010
	HOUSING D:15/12.5MM	13 PCS
	HOUSING D:12/9.5MM	2 PCS
	EURO BOLT	15 PCS
	SCREW #9 X 1 1/2"	42 PCS
	SCREW CAP	29 PCS
	SCREW M4 X 12	12 PCS
	SCREW M3.5 X 14	49 PCS
	SCREW M3.5 X 16	1 PC
	DOOR STOPPER	1 PC
	SCREW PAN HEAD #6 X 22	14 PCS
	LEG STUD	8 PCS
	SCREW M3 X 20	22 PCS
	CORNER BLOCK	22 PCS
	WEBBING	1 PC
	WOOD DOWEL M6 X 25	2 PCS
	WOOD DOWEL M8 X 25	54 PCS
	HANDLE	7 PCS
	HINGES 5/8"	8 SETS
	HINGES 1/4" (BLUE PLASTIC BAG)	4 SETS
	METAL RUNNER	1 SET
	ADJUSTABLE SHELF STUD	4 PCS

TOOL REQUIRED:

SCREW DRIVER HAMMER

STEP 2