

ASSEMBLING INSTRUCTIONS

1665

CAUTION :

THIS ITEM IS MADE OF LAMINATED PARTICLE BOARD AND MEDIUM DENSITY FIBRE BOARD

TO BE ASSEMBLED ON A DRY, SOFT, SMOOTH AND CLEAN SURFACE . DO NOT USE DETERGENT OR CHEMICAL. AVOID DAMP AND SUNLIGHT.

STEP 1	CHECK YOUR HARDWARE	6651
	SCREW #9 X 1 1/2"	12 PCS
	SCREW CAP	12 PCS
	WOOD DOWEL M8 X 25	12 PCS
	CORNER BLOCK	8 PCS
	SCREW M3 X 20	8 PCS
	SHELF SUPPORT	12 PCS
	HANDLE	1 PC
	SCREW PAN HEAD #6 X 22	2 PCS
	HINGES	3 PCS
	SCREW M3.5 X 14	13 PCS
	WEBBING	1 PC

TOOLS REQUIRED :	
	SCREW DRIVER
	HAMMER

STEP 2

WOOD DOWEL M8 X 25

DETAIL A

DETAIL B

STEP 3

DETAIL A

DETAIL B

SCREW PAN HEAD #6 X 22

SCREW M3.5 X 14

HINGES

HANDLE

STEP 4

SCREW #9 X 1 1/2"

STEP 5

STEP 6

SCREW #9 X 1 1/2"

STEP 7

DETAIL A

SHELF SUPPORT

DETAIL A

STEP 8

DETAIL A

STEP 9

DETAIL A

CORNER BLOCK

SCREW M3 X 20

DETAIL A

STEP 10

SCREW M3.5 X 14

DETAIL A

Hinges Adjustment Facilities

A. Lateral adjustment by the slacking screw adjusting via slot in the mounting plate

B. Vertical adjustment by the slacking the hinges arm

C. Front-to-Back adjustment by the slacking the hinges arm

STEP 11

SCREW CAP

DETAIL A

SCREW M3.5 X 14

WEBBING

DETAIL B

Move into final position and attach safety wall strap to wall.

Seek advice from qualified trades person on how to attach this to your specific wall.