

ASSEMBLING INSTRUCTIONS

2220

CAUTION :
THIS ITEM IS MADE OF LAMINATED PARTICLE BOARD AND MEDIUM DENSITY FIBRE BOARD
TO BE ASSEMBLED ON A DRY, SOFT, SMOOTH AND CLEAN SURFACE . DO NOT USE DETERGENT OR
CHEMICAL. AVOID DAMP AND SUNLIGHT.

STEP 1	CHECK YOUR HARDWARE	H2439
	SCREW #9 X 1 1/2"	10 PCS
	SCREW #9 X 2"	16 PCS
	HOUSING D:15 X 12.5MM	16 PCS
	EURO BOLT	16 PCS
	NYLON NUT	16 PCS
	WOOD DOWEL M8 X 25	37 PCS
	SCREW CAP	10 PCS

TOOL REQUIRED :

	SCREW DRIVER		HAMMER
---	--------------	---	--------

