

# ASSEMBLING INSTRUCTIONS

1660

## CAUTION :

THIS ITEM IS MADE OF LAMINATED PARTICLE BOARD AND MEDIUM DENSITY FIBRE BOARD

TO BE ASSEMBLED ON A DRY, SOFT, SMOOTH AND CLEAN SURFACE . DO NOT USE DETERGENT OR CHEMICAL. AVOID DAMP AND SUNLIGHT.

STEP 1	CHECK YOUR HARDWARE	6650
	SCREW #9 X 1 1/2"	22 PCS
	SCREW CAP	18 PCS
	WOOD DOWEL M8 X 25	23 PCS
	HANDLE	2 PCS
	SCREW PAN HEAD #6 X 22	4 PCS
	SHELF SUPPORT	5 PCS
	HINGES	4 PCS
	SCREW M3.5 X 14	16 PCS
	SCREW M4 X 30	8 PCS

  

TOOLS REQUIRED :		
	SCREW DRIVER	HAMMER

  

**STEP 2**

WOOD DOWEL M8 X 25

DETAIL A

DETAIL A

4

5

6

7

8

9

13

  

**STEP 3**

DETAIL A

11

DETAIL B

12

SCREW M3.5 X 14

HINGES

DETAIL A

DETAIL A

HANDLE

DETAIL B

SCREW PAN HEAD #6 X 22

  

**STEP 4**

SCREW #9 X 1 1/2"

1

6

9

7

4

13

  

**STEP 5**

SCREW #9 X 1 1/2"

2

7

4

13

  

**STEP 6**

SCREW #9 X 1 1/2"

MARKING TOP VIEW

2

4

8

1

  

**STEP 7**

Assemble panel 5 to side panel 1 and panel 8. Pull panel 2 to make room to joint panel 5.

2

8

1

5

  

**STEP 8**

SCREW #9 X 1 1/2"

2

8

1

5

9

6

  

**STEP 9**

65MM

BACK

SCREW M4 X 30

3

6

5

TOP

SIDE

Makesure back view top and side panel are flat before screw.

  

**STEP 10**

SCREW #9 X 1 1/2"

DETAIL A

SHELF SUPPORT

DETAIL A

2

8

9

1

  

**STEP 11**

2

1

10

  

**STEP 12**

SCREW M3.5 X 14

DETAIL A

DETAIL A

Hinges Adjustment Facilities

1

11

2

12

A. Lateral adjustment by the slacking screw adjusting via slot in the mounting plate

B. Vertical adjustment by the slacking screw adjusting via slot in the mounting plate

C. Front-to-Back adjustment by the slacking screw adjusting via slot in the mounting plate

  

**STEP 13**

SCREW CAP

DETAIL A

DETAIL A

1